

THE PINSKE EDGE

#4500

Inlay Corner Template

When you rout a 1" dado for installing a decorative inlay and you have an outside or inside corner, you will need to have an Inlay Corner Template.

This allows you to run a 3/4" Template Guide with a 1/8" Bit to remove the material in the corner and get it down to a 1/16" radius. Then you can chisel the little bit that left and have a square corner when seaming your inlays on a 90° corner.

The Pinske Edge
119 Main Street, P.O. Box 68
Plato, MN 55370 USA
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE
www.pinske-edge.com – info@pinske-edge.com