

# ***THE PINSKE EDGE***

**#91141**

## **Rabbit Stop Jig**

When you are routing your rabbet in the back of your deck for a coved backsplash, you may need a stop point (example – appliance garage, window). This template will allow you to finish your rabbet and square it up where your splash ends.

You simply make a line onto your countertop off of the template you made at the job site. Then, rout your rabbet stopping short of the line. Clamp the Rabbit Stop Jig onto the countertop with the scribe line on the jig lined up with your template line. Use a 1 ½ HP Plunge router with a 1/8" bit and a 3/4" Template Guide. This will clean up the corner down to a 1/16" radius. Square out what is left in the corner with a chisel. Finish by gluing the coved splash to the deck.

The Pinske Edge  
119 Main Street, P.O. Box 68  
Plato, MN 55370 USA  
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE  
[www.pinske-edge.com](http://www.pinske-edge.com) – [info@pinske-edge.com](mailto:info@pinske-edge.com)