

THE PINSKE EDGE

#91144N COVE BACKSPLASH JIG

STEPS FOR USING COVE BACKSPLASH JIG

- 1) Determine height of backsplash.
- 2) Rout bottom edge of backsplash straight.
- 3) Rip back splash to desired width.
- 4) Rout cove stick straight.
- 5) Rip cove stick to 15/16".
- 6) Glue backsplash to cove stick in cove jig. Clamp well.
- 7) Glue scribe to backsplash. Clamp well.
- 8) Rabbet deck 7/8" wide and 3/32" deep to receive backsplash.
- 9) Glue backsplash to deck.
- 10) Rout radius with cove router.

(See Cove Backsplash dimensions and Cove with Mitre details attached)

The Pinske Edge
119 Main Street, P.O. Box 68
Plato, MN 55370 USA
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE
www.pinske-edge.com – info@pinske-edge.com