

# ***THE PINSKE EDGE***

**#9500**

## **Independent Drainboard Template**

*Following the simple instructions below, will allow you to achieve the perfect drainboard in your solid surface countertop.*

1. Find the center of the sink and draw a line on to the countertop. This is done to make sure your drainboard pattern will be centered with the sink bowl when you are done routing.
2. Position the center of the template frame in conjunction with your centerline on the countertop. Insert your pattern into the template frame making sure that the taper is toward the sink.
3. The edge of the pattern should be placed 1” into the sink opening - your routed pattern will drain into the sink. Secure the template frame to the countertop using four (4) clamps.
4. We recommend routing your pattern in the following three (3) steps, starting with the outside pattern:
  - a) Make a light pass through the pattern.
  - b) With your second pass, you want to take out most of the material.
  - c) Lower your bit approx. four thousandths and make your final pass (this step will eliminate a lot of the sanding.)

The Pinske Edge  
119 Main Street, P.O. Box 68  
Plato, MN 55370 USA  
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE  
[www.pinske-edge.com](http://www.pinske-edge.com) – [info@pinske-edge.com](mailto:info@pinske-edge.com)