

# ***THE PINSKE EDGE***

## **#9601, #9602, #9603 Drainboard Patterns**

Find the center of the sink and draw a line onto the countertop. This is done to ensure that your drainboard pattern will be centered with the sink bowl when you are finished routing.

1. Position the center of the template in conjunction with your centerline. Make sure that the taper is toward the sink.
2. The edge of the pattern should be placed 1" into the sink opening, so your routed pattern will drain into the sink. Secure the template frame to the countertop using clamps or hot melt blocks.
3. We recommend routing your pattern in two passes. You'll need a 3/4" Template Guide and either a 1/2" or 5/8" Bit.

The Pinske Edge  
119 Main Street, P.O. Box 68  
Plato, MN 55370 USA  
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE  
[www.pinske-edge.com](http://www.pinske-edge.com) – [info@pinske-edge.com](mailto:info@pinske-edge.com)