

THE PINSKE EDGE

#205, #206, #207 J & L CLAMPS

The J Clamp is designed to hook into your substrate that is glued to the under side of your countertop (the buildup width can be up to 1 1/2" and the drop to 1 5/8").

Where the J Clamp will not work (as in the kitchen sink location), use the L Clamp and screw it to the substrate.

Both clamps are designed to clamp the cove stick against the dado you've routed into the deck. Place the clamps approximately 12" on center.

The Pinske Edge
119 Main Street, P.O. Box 68
Plato, MN 55370 USA
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE
www.pinske-edge.com – info@pinske-edge.com