

THE PINSKE EDGE

#2405/#2410

Move-Eze Wheels for Pinske Power Stands

These Wheels make it easy to move your jobs around the shop!

Assembly Instructions:

Take the Angle Bracket and center it on the lower Stand Cross Brace.

Using a clamp to secure it in place, mark the two holes on your Cross Brace (use a pencil, 17/64" drill bit or punch).

Remove the Angle Bracket and drill the 17/64" hole completely through.

Bolt the Angle Bracket onto the inside of the Brace using the 1/4-20x1-3/4" Bolts supplied.

Take the Wheel Assembly and bolt that to the Angle Bracket with the 1/4-20 x 3/4" Bolts supplied. Make sure they are tightened.



The Cam will raise the Power Stand off the floor so that you can move your jobs around. When you are working on your tops, simply lower the Cam Handle and the Stand will set on the floor.

The Pinske Edge
119 Main Street, P.O. Box 68
Plato, MN 55370 USA
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE
www.pinske-edge.com – info@pinske-edge.com