

# ***THE PINSKE EDGE***

## **#3312 AIR CIRCLE COMPASS**

**The Pinske Edge Circle Compass may be used for countertops, tables, pinstripes, cleaning off your edge treatment and even making your radius edge treatment.**

1. To Assemble: Attach the brass swivel fitting to the top of the cup.  
The two 5-16 x 24 nuts on the base plate are for fine tuning the finished radius dimension. To run the Air Circle Compass, you need a constant air supply (80 psi). After attaching the air supply, turn ON the pneumatic switch to secure the cup. Adjust the bent arms so that the router base sits flat on the countertop.
2. For the radius, find the center of the material and scribe a 6" circle.
3. The Circle Compass makes circles from 13" to 90" in diameter and adjusts with only an allen wrench and an open-end wrench.
4. Referencing from the inside edge of the router bit, set the Circle Compass at the pivot center to the desired radius.
5. Start with the router raised and rout the entire radius.
6. Move the router in by adjusting the Circle Compass arms to the desired dimension. Rout a perfect radius or pinstripe EVERY time!

The Pinske Edge  
119 Main Street, P.O. Box 68  
Plato, MN 55370 USA  
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE  
[www.pinske-edge.com](http://www.pinske-edge.com) – [info@pinske-edge.com](mailto:info@pinske-edge.com)