

THE PINSKE EDGE

#8083, #8084, #8086, #80865, #80866, #80867, #80868 RIGID SEAMING CUPS

Rigid Seaming Cups work great for pulling smooth seams together. The rigid construction of the pads levels the top surface of your countertop as it pulls together the seam. The pads are made of UHMW with a rubber gasket for a seal. These cups are available for use with compressed air or a vacuum pump – packages are available in several ways.

Operation

We recommend one (1) set of Rigid Seaming Cups per 25” seam. After applying seam adhesive to your solid surface seam, pull the seam together with your hands. Place the Rigid Seaming Cups over the seam – both valves should be OFF. On the Rigid Seaming Cup closest to the air supply, open the valve (turn the lever upright) to ON. Push down on the cup to make a tight seal. Repeat with the next Seaming Rigid Seaming Cup. (Remember to work from the cup *closest* to the air supply to the *farthest*.) Once all valves are ON and all cups are secured, then pull the Cam-lock handles to pull the seam together. The seam is now aligned and clamped. Let the adhesive set before removing the Rigid Seaming Cups. To remove the cups, turn the valves to off and push the relief valves.

Air Pressure – The Venturi Vacuum Generator will take 2.15 Standard CFM and should run at 75 PSI.

Maintenance

Keep the gaskets clean from dust with a quick brush off. If you get adhesive on the gasket, wipe off with alcohol. If the gasket becomes damaged, you can replace them with Product # 011253.

Compressed Air Supply – Air filters and drains are recommended to keep your air from becoming oily or contaminated.

The Pinske Edge
119 Main Street, P.O. Box 68
Plato, MN 55370 USA
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE
www.pinske-edge.com – info@pinske-edge.com