

THE PINSKE EDGE

#8087 Power Grips

We recommend cleaning the rubber pads on your Power Grip on a regular basis. Use a Citrus cleaner to keep the pads clean and soft. Also be sure to clean the surface area the pads adhere to – this will ensure a tight secure grip. Be sure to pump up the grip until the plunger is fully depressed.

POWER GRIP CHECK LIST

If you experience problems, we recommend reviewing the following checklist. Call or fax us with any specific questions.

- #1 Remove the felt washer on the rubber pad and place your thumb over the hole. Depress the pump plunger. If the pump comes back out, there are a few things to check out.
 - A. Pull the pump out and look at the rubber seals to see if they are worn or deformed. If so, replace; but you must hone the inside of the bore out so that you have a proper seal and smooth bore to keep the seal from galling. Use a silicone based grease to lubricate rubber.
 - B. Pull Release Valve on the side of the Cup off and clean if necessary. Replace the o-ring and checkball. You must clean the check ball seat area and air stem of valve to free it from dirt buildup. Once you have done this recheck by doing Step #1 or take a piece of solid surface material and test on that. Note the time when you clamp it down. If the pump handle comes out within 10 minutes, more problems exist.

- #2 Check the rubber pad for softness. If the edge is hard, replace the pad. If it's OK, clean it thoroughly with citrus cleaner or #2 3M Brand solvent. An old toothbrush works well to get in the grooves. You must have outside edge grooves totally clean to obtain a good seal. Use of the citrus brand cleaner will maintain your pads longer.

The Pinske Edge
119 Main Street, P.O. Box 68
Plato, MN 55370 USA
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE
www.pinske-edge.com – info@pinske-edge.com

THE PINSKE EDGE

Note: If you're still having problems, check the valve for cracks where the stem is soldered on; otherwise you may have an alignment problem where it enters the cup. (Also use a little grease at this point to seal it up better and also on small o-ring).

We've put together a kit which costs \$45.00 – included in the kit is: Valve, Pump, Checkball, O-ring, Felt Pad and Lubricant. Or, the parts can be purchased individually as follows:

- | | | |
|-----|--|----------------|
| (1) | Valve (P/N 010184) | (\$23.00 each) |
| (1) | Pumps (P/N 010189) | (\$21.00 each) |
| (1) | Check Balls (P/N 010191), O-Rings, (P/N 010190) Felt Pads (P/N 010192) | (\$ 1.00 each) |
| (1) | Lubricant (P/N 010186) | (\$ 3.00 each) |

.....**You may also wish to purchase the following**.....

- | | | |
|-----|-----------------------------|----------------|
| (1) | Can Citrus Cleaner (P/N 62) | (\$32.00 each) |
| (1) | Pad (P/N 010193) | (\$28.00 each) |
-

If you prefer, you may also simply return your power grip to The Pinske Edge. We can immediately replace your returned grip with a reconditioned power grip. The cost is only \$75.00 each; you will receive a reconditioned (like new) power grip.

The Pinske Edge
119 Main Street, P.O. Box 68
Plato, MN 55370 USA
Fax – 320-238-2385 - Phone 320-238-2196 or 1-800-TPINSKE
www.pinske-edge.com – info@pinske-edge.com